

Installation Method Regupol 4515 Multi Acoustic

Heckmondwike can recommend the use of Regupol 4515 multi acoustic 4.5mm thick underlayment with Supacord, Broadrib & Hobnail Sheet.

The installation recommendations are different from the standard sheet installation. Regupol to be fully stuck to the substrate with F3. Then a full spread of F40 High Tack Dual bond adhesive applied on top of the Regupol and left to dry completely to a clear tacky film. Heckmondwike Supacord, Broadrib or Hobnail should be placed onto F40 and pressed from the centre outwards to exclude air, and then apply pressure by rolling with a 68kg flooring roller from end-to-end and side-to-side, to ensure overall contact with the adhesive.

This system has been chosen so that at the end of the carpet's life or any installation issues, the carpet can be uplifted, leaving the Regupol in place.